


# How to...

## Adjust or Align Footbar

### Steps 1 & 2



After frequent use, the fasteners for the footbar mechanism may loosen and as a result, the footbar may angle upwards slightly at one end.

**NOTE:** *This will require two people*

## Adjust and Level

1. Loosen all socket head cap screws and or bolts on footbar swing arm mechanism
2. The helper applies downward pressure to the footbar while the socket-headed cap screws and nuts are being tightened.

**IMPORTANT:** *Apply an equal amount of torque force on all fasteners to ensure the footbar is restored back to its original horizontal alignment.*

For more information contact our Customer Service

1.800.910.0001 ext. 288 | 0800.328.5676 ext. 288 (UK) | 416.482.4050 ext. 288 (Customer Care)  
customerservice@merrithew.com | [merrithew.com](http://merrithew.com)