


How to... Adjust or Align Footbar

Steps 1 & 2



After frequent use, the fasteners for the footbar mechanism may loosen and as a result, the footbar may angle upwards slightly at one end.

NOTE: This will require two people

Adjust and Level

1. Loosen all socket head cap screws and or bolts on footbar swing arm mechanism
2. The helper applies downward pressure to the footbar while the socket-headed cap screws and nuts are being tightened.

IMPORTANT: Apply an equal amount of torque force on all fasteners to ensure the footbar is restored back to its original horizontal alignment.